


Ersatzteilliste



ITEM NO.	REF. NO.	DESCRIPTION
1	CS0001	BASE
2A	CS0002A	SUPPORT BRACKET
2B	CS0002B	SUPPORT BRACKET
3	CS0003	GUIDE ARM (2)
4	CS0004	ASSEMBLY ROLLER BRACKET
5	CS0005	ASSEMBLY ROLLER GASKET
6	CS0006	LONG ASSEMBLY ROLLER (2)
7	CS0007	SHORT ASSEMBLY ROLLER (2)
8	CS0008	LONG ASSEMBLY ROLLER WASHER (2)
9	CS0009	SHORT ASSEMBLY ROLLER WASHER (2)
10	CS0010	NUT, JAM
10A	CS0010A	GASKET (2)
11	CS0011	INLET AXLE
12	CS0012	O-RING (2)
13	CS0013	PLASTIC GASKET
13A	CS0013A	SPRING PLASTIC GASKET
14	CS0014	AIR BASE
15	CS0015	CLAMP BASE
16	CS0016	CLAMP
17	CS0017	CLAMP SPRING
18A	CS0018A	FRANGE, LEFT
18B	CS0018B	FRANGE, RIGHT
19	CS0019	DRIVE SPRING

ITEM NO.	REF. NO.	DESCRIPTION
20	CS0020	REEL COVER
21	CS0021	AXLE NUT
22	CS0022	OUTLET CONNECTOR (2)
23	CS0023	COPPER BUSH (2)
24	CS0024	AIR HOSE
25	CS0025	PLASTIC GASKET
26	CS0026	PROTECTIVE SPRING
27	CS0027	BALL STOP
28	CS0028	HEX SCREW (4)
29	CS0029	HEX SCREW (16)
30	CS0030	FLAT SCREW (4)
31	CS0031	FLAT SCREW (4)
32	CS0032	NUT (4)
33	CS0033	NUT (24)
34	CS0034	GASKET (4)
35	CS0035	GASKET (24)
36	CS0036	GASKET
37	CS0037	NUT
38	CS0038	NUT (4)
39	CS0039	FLAT SCREW (5)
40	CS0040	GASKET (4)
41	CS0041	SWIVEL CONNECTOR
42	CS0042	COUPLER